



HD Conference Camera

User Manual




1. Product Description


1.1 Front




1.2 Front



2. Packing List



4. Remote Control Button Description



★ Attenions for Remote Control

1. Please check whether the indicator corresponding to the camera selection area is on or not.
2. If the remote control doesn't work, please replace batteries.
3. Make sure the Number keys on the camera selection area are consistent with the remote control address in the menu.

3. Performance Characteristics

Model No.	VHD10H	VHD20H	VHD12H
Image Sensor		Sony IMX327 1/2.8" CMOS	
Effective Pixels		2.07MP	
Optical Zoom	10x zoom	20x zoom	12x zoom
Lens	f=4.32-40mm	f=5.5-110mm	f=4.1-49.2mm
Aperture	F1.76 - F3.0	F1.6-3.5	F1.28-2.88
Horizontal Angle	67.5°(W)-8.8°(T)	55.9°(W)-3.2°(T)	70.28°(W)-6.57°(T)
Vertical Angle	40.2°(W)-4.3°(T)	32.2°(W)-1.8°(T)	42.06°(W)-3.76°(T)
Diagonal Angle	75.4°(W)-8.8°(T)	61°(W)-3.64°(T)	78.36°(W)-7.5°(T)
Video Format	1080p@60/50/30/25fps, 720p@60/50/30/25fps		
Video Encoding Format	H.264, H.265, MJPG, YUY2		
Backlight Compensation	Support		
SNR	>50dB		
Focus	Auto / Manual		
Digital Noise Reduction	2D & 3D Noise Reduction		
Exposure	Auto / Manual		
I/O Interface			
Video Interfaces	HDMI, USB3.0, RJ45		
Video Compression Format	H.264, H.265, MJPG, YUY2		
LAN	10M/100M/1000M adaptive Ethernet port, Support POE IEEE802.3at		
Network Protocol	NDI/HX2, RTSP, RTMP, ONVIF, GB28181, Support VSCA Over IP		
Control Protocol	VSCA/Pelco-D/Pelco-P, Baud Rate: 9600/4800/38400/2400		
Control Interface	RS232, RS485, USB3.0 TYPE-B(UVC1.1), RJ45		
I/O Interface			
Pan/Tilt Rotation	±175°, -90° ~ +90°		
Pan Control Speed	0.1~80°/sec		
Tilt Control Speed	0.1~60°/sec		
Preset Number	User can set up to 255 presets (10 presets by IR remote)		
I/O Interface			
Operation Systems	Windows 7, Windows 8.1, Windows 10, Windows 11; Android, Mac OS™ 10.10 or higher, Linux (Required to support UVC.)		
Input Voltage	DC 12V		
Input Current	2.0A (Max.)		
Power Consumption	13W (Max.)		
Store Temperature	-10°C ~ +60°C		
Store Humidity	20% ~ 90%		
Working Temperature	-10°C ~ +50°C		
Working Humidity	20% ~ 80%		
Dimension (W*H*D)	247.1*152*169.6mm/285.21*197mm(m before / after packing)		
N.W / G.W.	1.37kg/2.45kg (net / gross weight)		
Accessory	1 x Camera; 1 x USB Cable; 1 x Power Adapter; 1 x Wall Mount; 1 x Manual		
Mfg. Warranty	3 Years standard Parts & Labor warranty		

5.4 Level 2 Menu-Image

Color	
→ Mode	Manual
Iris	F2.2
Shutter	1/30
Gain	00
Flicker	50Hz
[Return]	

Flip: On/Off (Enable/disable the picture flip up/down)
 Mirror: On/Off (Enable/disable the picture flip left/right)
 USB Mode: BULK (Adjust between Isochronous transfers mode and Bulk transfers mode)

5.5 Level 3 Menu-Video Format

Video Format	
→ Mode	SAE
Shutter	1/30
Gain	00
Flicker	50Hz
[Return]	

Exposure	
→ Mode	AAE
Iris	F2.2
Shutter	1/30
Gain	00
Flicker	50Hz
[Return]	

Bright: Optional item is 0-17 (Only effective under Bright mode)

5.3 Level 2 Menu - Color

Color	
→ Brightness	50
Contrast	50
Hue	50
Saturation	50
Sharpness	50
WB Mode	Auto
Rtuning	00
Btuning	00
[Return]	

5.6 Level 2 Menu- P/T/Z

P/T/Z	
→ Acc Curve	Middle
L/R SET	On
ZOOM Speed	6
AF Zone	Bottom
AF Sense	Low
AF Scene	Normal
[Return]	



6. Common Operation Instructions

6.1 Camera Select

Set the IR remote control's address to control the corresponding camera, option item 1/2/3/4



6.2 Camera Direction Control



Note: Press the direction key when you need to adjust the angle. If you want to move the camera slowly, just click the direction key; If you want to move the camera fast at a large scale, just long-press the button; If you want to adjust the Pan-Tilt direction, just press and hold the L/R button for 10S.


6.3 Camera Focus Mode Control

【AUTO】 Switch the focus mode to AUTO

【MANUAL】 Switch the focus mode to MANUAL

【FAR】 Far focus manually

【NEAR】 Near focus manually



6.4 Camera Zoom Control

Press any one of the 4 【ZOOM】 to make the zoom functioning. These 4 keys are not applicable for fixed focus cameras.



6.5 Preset Setup, Call, Cancel


(1) Reserve Preset: Press 【PRESET】 , then press one of the numbers (0-9) to reserve a preset that corresponds to the NUMBER.

Note: You can setup 10 presets at most by the remote control.

(2) Call Preset: Press the NUMBER (0-9) directly to call the reserved preset.

Note: It won't work if there's no preset reserved in the corresponding number.

(3) Remove Preset: Press 【RESET】 , then press one of the number (0-9) to remove a preset that corresponds to the NUMBER.



5. Brightness: Optional item is 0-99

5. Contrast: Optional item is 0-99

5. Hue: Optional item is 0-99

5. Saturation: Optional item is 0-99

5. Sharpness: Optional item is 0-99

5. WB mode: Auto/Manual/VAR/Indoor/Outdoor/Onepush

When the WB mode is Auto, the Rtuning and Btuning value can be tuning.

The range is 0 to 99.

When the WB mode is Manual, the sub-menu will be as shown below:

Color	
→ Exposure	
Color	
Image	
P/T/Z	
Communication	
Information	
Restore Default	
Language	English
[Home]	Enter
[Menu]	Back


When the WB mode is VAR, the sub-menu will be as shown below:

Color	
→ Exposure	
Color	
Image	
P/T/Z	
Communication	
Information	
Restore Default	
Language	English
[Home]	Enter
[Menu]	Back

Language: Support Chinese/English

Press the 【△】 button on the Remote to enter level 2 sub-menu

6.6 RS-232 Interface Distribution




VISCA RS-232 IN

1.N.C.
2.N.C.
3.TXD
4.GND
5.RXD
6.N.C.
7.N.C.
8.N.C.

6.7 RS-485 Interface Distribution

PIN NUM	FUNCTION
A	DTR IN+(connect to RS-485)
B	DSR IN-(connect to RS-485)

A B



7. Network Function



7.1 Equipment installation

Connect HD video camera to your internet or your PC via network cable, or connect by Switch/Router.

You can log into the camera's web interface with the default or modified IP. (Different models have different IP, please check the default IP at the bottom of the camera.)

7.1.1 How to query the IP address of your PC (Note the text in the box)

Windows Settings




7.3 Input <http://192.168.0.206> to IE (better with IE or Google web browser), then a login window will pop up; Input user name: admin, password: admin; and choose language: English, shown as below, whether the IP already exists.

7.3.1 When logging in for the first time, will be prompted to change your password. Users can change the passwords and save it.



7.3.2 After successfully login, you will enter the Video viewing interface. In the setting interface, you can set Pan and tilt control, Zoom, Focus, and set, call, clear of preset positions, etc.



7.6.1.2 Restart the camera and prompts "Upgrade succeeded". Log in to the network and check whether the software version is consistent with the upgrade file to ensure that the upgrading is successful. Then click "Restore factory default" to restart and restore the parameters to the factory default setting. (IP default 192.168.0.206, User default: admin, password default: admin)

7.7 VISCA over IP

VISCA protocol is transmitted over IP to reduce the trouble of RS232/RS485 wiring(controller must support IP communication function)

Communication port specifications:

Control port: RJ45

IP protocol: IPv4

Transport protocol: UDP

IP address: set through the web

Port address: 52381

Scope of application: the same network segment

9. Trouble Shooting

Before requesting service to service engineer, please refer to the following methods to remove failures. If the failures still can't be solved, please contact us for assistance.

Q: The video of the camera cannot be displayed on the screen.

A: Please check the connection between power cable, video cable, camera and monitor, fix the connector on each end.

Q: It's unable to Pan, Tilt and Zoom camera.

A: Because the menu was displayed on monitor. Please re-operate after exiting the menu.

Q: Why the camera rotates for about 10 seconds after power on?

A: This is the normal self-test of the camera.

Q: Poor Image quality while using in church or other low-light conditions.

A: Press menu (ON/OFF) to adjust backlight effect to suit the church lighting properly.

Q: Remote control is not working or insensitive.

A: ①Not work, please replace batteries.
②Not sensitive: Choose the correct "IR select" number to correspond to the camera. Control the camera within 10m (32.8ft). Remove the obstacles. Aim at the sensor which is in front of the camera when controlling it.

Q: USB interface is not identifiable.

A: Please check if the USB cable and extension cable are well connected or not. If yes, change to another USB interface and try to connect again.

Q: It won't be controlled via RS-232/RS-485 when camera connect to PC.
A: Make sure it is a correct connection between the camera and PC. (Refer to RS-485 and RS-232 Pins distribution on page 12).

Q: Why no ceiling mount bracket?

A: Camera comes with wall mount only. ceiling mount or tripod brackets need to buy separately.


Q: Does this camera has built-in mic?

A: No, this camera comes with no built-in mic.

Q: Can we control the camera only by the remote control?
A: You can control the camera by remote control, keyboard controller (joystick), and software.


7.4 Video streaming

7.4.1 Select "Setup" - "Video Settings" - "System Settings" to enter the following interface:



7.4.2 RTSP video streaming

Select "Setup" - "Network Settings" - "RTSP" to enter following interface:



Configure parameters according to the network environment.

If the camera default IP address is 192.168.0.206, then the way to get RTSP video streaming as below:

Default RTSP main streaming address:

<rtsp://192.168.0.206:554/live/av0> (av0 Main)

Default RTSP sub streaming address:

<rtsp://192.168.0.206:554/live/av1> (av1 Sub)

7.4.3 RTMP video streaming

Select "Setup" - "Network Settings" - "RTMP" to enter following interface:

7.5.1 Change the camera IP address to: 192.168.110.206


7.5.2 Default Gateway: 192.168.110.254

7.5.3 Alternate DNS: 192.168.110.7

7.5.4 Preferred DNS: 192.168.110.8

7.5.2 Return PC's IP to the original IP address, and select Obtain an IP address automatically

7.5.2.1 Select "Setup" - "Network Settings" - "System Settings" to enter the following interface:



7.6 Software upgrade (upgrade if there is a new version)

7.6.1 Select "Setup" - "Maintenance" - "System Upgrade" to enter the following interface:




7.6.1.1 Open upgrade file to Upgrade automatically if needed.


8. Installation Instructions

8.1 Surface Installation

Put the camera on the desk flatly, and make sure the camera is in a horizontal position. If you want to put the camera on an oblique surface, please make sure the angle of inclination is less than 15 degrees to ensure the camera's pan&tilt works normally.



8.2 Wall Mount Installation



10. Maintenance Services

All products purchased from our company are guaranteed to keep in good repair for 36 months. If there are any quality problems during the guarantee period, we will maintain them for free.

Under any of the following warranties, related maintenance costs will be collected:

1. Product was not normally used.

2. Fire, electric shock, outside object collapse or other natural disasters causing the equipment damaged.

3. Unauthorized repair, misuse, abuse or change.