


# Speakerphone Manual


Version V2.0

## 1. Packing List

### 1. USB device



Speakerphone




USB Cable




Manual


### 2. Bluetooth device




Speakerphone



USB Cable



Manual




Bluetooth Dongle




OTG Adapter

## 2. Charging

Plug the device into a USB power source. The device lasts for up to 6 hours of talk time and takes approximately 3 hours (5V/500mA) to fully charge.





## 3. Low battery warning



When the battery is low, the led lights turn red and flash with voice prompt.

## 4. Button Function



3.5mm audio output interface

Type-C interface


Powerstatusindicator

Speaker status indicator


ON/OFF




Volume button




Speaker mute button




Answer/Hang up



Microphone mute button



Bluetooth button



ON/OFF



Microphone status indicator



Bluetooth status indicator (only for Bluetooth device)



Powerstatusindicator




Speaker status indicator



ON/OFF


## 5. LED Indicator Function



Powerstatus indicator

Volume status indicator

Key indicator



Powerstatus indicator


Volume status indicator

Microphone status indicator

Bluetooth status indicator (only for Bluetooth device)	Red light on	Bluetooth pairing
Microphone status indicator	Red light on	Microphone mute
Powerstatusindicator	Green light on	Powered on
Speaker status indicator	Green light on	Speaker working normally
	Red light on	Speaker mute

## 6. Connection Introduction

### 6.1 USB Connection




USB connection




1. We suggest you to use the original USB data cable to connect the speakerphone when connecting computer or other audio and video terminals;

2. Turn on automatically after connection; once connected to your computer, it will automatically power on. It will automatically power off after 10 minutes of inactivity on no source.



## 6.2 Bluetooth Connection



1. When the device is under normally working condition, press "X" to turn on Bluetooth for pairing. Then the Bluetooth status indicator will flash;
2. Put the mobile device in the Bluetooth device search mode, and select the model of the device. After Bluetooth connection is succeeded, the Bluetooth status indicator will be ON.
3. Plug the Bluetooth Adaptor in your computer or other devices to enter pairing mode. The Bluetooth adapter will search for the Bluetooth automatically, and establish Bluetooth connection between the speakerphone and the adapter. After a successful connection, the Bluetooth indicator is always on.
4. Each time you power on the device, it will automatically connect with the last successfully connected device if available.
5. To disconnect Bluetooth, please press the Bluetooth button again.

## 6.3 Headset Connection



Connect to headset jack using a 3.5mm cable.

## 7. Technical Specifications

Product Type	USB Speakerphone	Bluetooth Speakerphone
Picture		
Bluetooth	N/A	BT 5.0
Battery	N/A	2400mAH(Built-in lithium battery) Music time (up to 8 hours ) Battery life(call) up to 6 hours. Charge time up to 3 hours
Connection type	USB/AUX	USB/Bluetooth/AUX
Meeting room size	15-30m <sup>2</sup>	
Meeting with	3-12 attendees	
Pickup range	5 meters (16.4 feet)	
Mics	2x professional mics array	
Microphone type	Omni-directional (360 degree pickup range)	
Microphone sensitivity	-29dBFS	
Noise reduction	Yes	
Full duplex audio	Yes	
AEC	Yes	
Frequency range	100Hz to 22kHz	
Speaker	5W/95dB	
Interface	1 x Type-C, 1 x 3.5mm audio port	
System requirements	Windows 7/8/10 or above, MacOS 10.7 or above, Chrome OS V29.01547 or above	
Application support	Software: Skype, FaceTime, Zoom, Microsoft Teams, Google Hangouts, OBS and Xsplit, etc.	
Work temperature	0° -- 50°C	
Storage temperature	-10° -- +60°C	
Work humidity	20% -- 85% RH (non-condensing)	
Power supply	USB:5V DC @ 500 mA Maximum	
Product size	160mm*160mm*38mm/221mm*190mm*55mm((before / after packing)	
Product weight	0.44KG / 0.77KG(Net / Gross Weight)	

## 8. Warranty

All products purchased from our company are guaranteed to keep in good repair for 36 months. If there are any quality problems during the guarantee period, we will maintain them for free. Under any of the following conditions, related maintenance costs will be collected:

1. Product was not normally used.
2. Fire, electric shock, outside object collapse or other natural disasters causing the equipment damaged.
3. Unauthorized repair, misuse, abuse or change.

## Warranty Card

Thank you very much for choosing our product.

### User Info

Name \_\_\_\_\_ Tel \_\_\_\_\_

Email \_\_\_\_\_ Post code \_\_\_\_\_

Address \_\_\_\_\_

### Product information

Product Name \_\_\_\_\_

Factory Serial Number \_\_\_\_\_

### Fault description

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

### Attention

1. This card is considered as the protection to fix warranty, so please reserve them carefully. Please fill in truthfully.

2. Please indicate the model number, Factory Serial number and the detailed description of the fault information.